


## RTU Digital Input Quick Operation Guide

### Catalog

|   |    |
|---|----|
| RTU Digital Input Quick Operation Guide.....                                  | 1  |
| 1. RTU Cable Connection.....  | 2  |
| 2. RTU Counter input configuration.....                                       | 2  |
| 2.1. RTU WEB Page configuration.....  | 2  |
| 2.1.1. Login RTU local web-based page.....                                    | 2  |
| 2.1.2. Digital input configuration.....                                       | 3  |
| 2.1.3. Alarming/Active reporting configuration.....                           | 4  |
| 2.2. Configure RTU management platform.....                                   | 7  |
| 2.2.1. Configure RTU server.....  | 7  |
| 2.2.2. Setting RTU Identity.....  | 7  |
| 2.2.3. Login to RTU software management platform.....                         | 8  |
| 2.2.4. Register RTU ID.....   | 8  |
| 2.2.5. Setting connected interface.....                                       | 8  |
| 2.2.6. Digital input parameters configuration.....                            | 9  |
| 2.2.7. Alarming/Active reporting configuration.....                           | 10 |
| 2.2.8. Alarming query /Active reporting query configuration.....              | 11 |
| 3. Remote control the digital input on RTU management platform.....           | 12 |
| 3.1. Enter into RTU management platform.....                                  | 12 |
| 3.2. Configuration Digital input.....   | 12 |
| Appendix 1: Indicator description.....  | 13 |
| Appendix 2: Faulty analysis.....  | 14 |
| 4.1. Power indicator is off.....  | 14 |
| 4.2. Online indicator is off.....   | 14 |
| 4.3. ACT indicator is off.....  | 14 |
| 4.4. All the indicators are normal, but it still can not to communicated..... | 14 |
| 4.5. Too slowly to enter into RTU WEB page.....                               | 14 |

## 1. RTU Cable Connection



1. SIM card slot: Please ensure the RTU is powered off before pulling or plunging SIM card;
  2. Power wire (PWR —black with white, GND—black);
  3. RS232(D/RX—blue, D/TX—brown, GND—black): Please use this RS232 serial port to connect PC; USD forwarder to RS232 can be instead of if there is no RS232 serial port on PC;
  4. The cable connected to PC;
  5. Digital input DIG (same as counter input) and 8 digital inputs ( low level input range from 0-3.3V, high level input range from 5-24V). Those 6 roads inputs can be valued as counter inputs (the counter frequency is 1KHZ) or digital input DIG.
  6. 2G/3G/4G antenna;
- Please power on RTU after connection.

## 2. RTU Digital input configuration

### 2.1. RTU WEB Page configuration

#### 2.1.1. Login RTU local web-based page



1. Open the browser and enter into the default IP address: 192.168.1.2; then fill in account name: admin, password: admin.
2. To choose English version on the left;
3. RTU IP address: Please change RTU's IP address to avoid conflicts when you use cable connect RTU with digital.

## 2.1.2. Digital input configuration

### 8 IO mode selection

RTU

- Server
- ETCP
- PWM/Relay
- Digital input/Count**
- Digital Output
- AD
- alarm
- other

| IO NO | Digital Input/Count |
|-------|---------------------|
| 3     | Digital input       |
| 4     | Digital input       |
| 5     | Digital input       |
| 6     | Digital input       |
| 7     | Digital input       |
| 8     | Digital input       |

Apply

### Digital input configuration

| IO NO | MODBUS level logic | Acquisition updated time | Work Type | Alarm trigger conditions | Mobile phone number for alarm | Alarm contents | Enable | Edit |
|-------|--------------------|--------------------------|-----------|--------------------------|-------------------------------|----------------|--------|------|
| 1     | 0-low 1-high       | 0                        | Query     | low level                | ...                           | ...            | NO     | Edit |
| 2     | 0-low 1-high       | 0                        | Query     | low level                | ...                           | ...            | NO     | Edit |
| 3     | 0-low 1-high       | 0                        | Query     | low level                | ...                           | ...            | NO     | Edit |
| 4     | 0-low 1-high       | 0                        | Query     | low level                | ...                           | ...            | NO     | Edit |
| 5     | 0-low 1-high       | 0                        | Query     | low level                | ...                           | ...            | NO     | Edit |
| 6     | 0-low 1-high       | 0                        | Query     | low level                | ...                           | ...            | NO     | Edit |
| 7     | 0-low 1-high       | 0                        | Query     | low level                | ...                           | ...            | NO     | Edit |
| 8     | 0-low 1-high       | 0                        | Query     | low level                | ...                           | ...            | NO     | Edit |

|  |   |
|--|---|
| IO NO  | <input type="text" value="1"/>                        |
| MODBUS level logic   | <input type="text" value="0-Low 1-High"/>             |
| Acquisition updated time   | <input type="text" value="0"/> (0~0)                  |
| Work Type  | <input type="text" value="Query+active reporting"/> 5 |
| Alarm trigger conditions   | <input type="text" value="Low level"/> 6              |
| Enable   | <input type="text" value="YES"/> 7                    |
| Mobile phone number for alarm(up to 10, with<br><input type="text" value="18205924030"/> 8 |   |
| Alarm contents (up to 140 bytes)<br><input type="text" value="123"/> 9                     |   |
| <input type="button" value="Apply"/> 10 <input type="button" value="Reset"/>               |   |

- Click "Digital/Count" option on the left menu bar;
- Select "Digital" from the "Digital/Count" option;
- Click "Apply";
- Click "Edit" to edit the relative digital input parameters;
- Work type: To select the relative alarming mode, otherwise, no alarming. Alarming/active report's configure see as 2.1.3.
- To set the alarm trigger conditions: Only valid for alarming. For active report, it will trigger an alarm when the time is up;
- To enable this current count input interface;
- The mobile phone number for alarming: up to 10 number, separated by ",".
- Enter the alarm contents (no more than 140 bytes).
- Click "Apply"; and then power off RTU first and power on again to reboot, or click "reboot", which is on the top right of this page.

### 2.1.3. Alarming/Active reporting configuration

#### 2.1.3.1. Alarming configuration



### Alarm configuration

Alarm Way **2**

Alarm interval time **3**  (3~3600s)

Alarm Times **4**  (0~255)

Alarm receiving mobile phone number(up to 10, with

18205925040 **5**

**6**

1. Click "RTU--Alarm" on the left of menu bar on the page;
2. Alarm Way: Network alarming and SMS alarming. (currently, the module of MC2716, mu609, M305 support SMS alarming; the others are only support network alarming, 2G communication module can not support SMS due to no SMS port);
3. To set the alarm interval time;
4. Alarm times: if the value is 0, then RTU will send alarming info once time is up;
5. The mobile phone number for alarming: up to 10 number, separated by ",";
6. Click "Apply".

**Note:** You can not query the alarm info according to RTU WEB page, but by RTU management platform. For more details, refer to 2.2.8.1.

### 2.1.3.2. Active report configuration



#### Active reporting configuration

Allow to active reporting or not 2

Active reporting interval time 3  (3~3600s)

Active reporting type 4

The receiving mobile phone number for active reporting(up to 10, with

5

6


1. Click "RTU--Alarm" on the left of menu bar on the page;
2. Enable "Allow to active reporting or not";
3. To set the alarm interval time;
4. Alarm Way: Network alarming and SMS alarming. (currently, the module of MC2716, mu609, M305 support SMS alarming; the others are only support network alarming, 2G communication module can not support SMS due to no SMS port);
5. The mobile phone number for alarming: up to 10 number, separated by ",";
6. Click "Apply".

**Note:** You can not query the active report info according to RTU WEB page, but by RTU management platform. For more details, refer to 2.2.8.2

## 2.2. Configure RTU management platform

### 2.2.1. Configure RTU server

Please refer to 2.1.1 to enter into RTU WEB page.



| NO | Server IP address | PORT | Network protocol | Data center protocol    | Local Port | Enable | Edit |
|----|-------------------|------|------------------|-------------------------|------------|--------|------|
| 1  | bbs.nju.edu.cn    | 23   | TCP              | RTU management platform | 0          | YES    | Edit |
| 2  |                   | 0    | TCP              | RTU management platform | 0          | NO     | Edit |
| 3  |                   | 0    | TCP              | RTU management platform | 0          | NO     | Edit |
| 4  |                   | 0    | TCP              | RTU management platform | 0          | NO     | Edit |
| 5  |                   | 0    | TCP              | RTU management platform | 0          | NO     | Edit |
| 6  |                   | 0    | TCP              | RTU management platform | 0          | NO     | Edit |
| 7  |                   | 0    | TCP              | RTU management platform | 0          | NO     | Edit |
| 8  |                   | 0    | TCP              | RTU management platform | 0          | NO     | Edit |

NO: 1

Server IP address: bbs.nju.edu.cn

PORT: 23

Network protocol: TCP

Data center protocol: RTU Management Platform

Local Port: 0


Enable: YES

Apply 4 Reset

- Click "RTU-->Server" on the left menu bar, see as below picture;
- Click "Edit";
- Setting the parameters of RTU sever as below:  
NO.: The number of server IP address  
Sever IP address: To enter RTU server's IP address: 27.154.56.174 (Caimore RTU management platform)  
Port number:18000,  
Data center protocol: RTU management platform  
Enable server: select "YES"
- Click "Apply" to finish.

## 2.2.2. Setting RTU Identity

### RTU Identity



RTU ID: 00000071 1

MODBUS ID: 01 (Hex:01~F7)


SIM number: 138888888888

Apply 2 Reset

- RTU ID: To enter the distribute ID No. ( i.e: 71). This ID can be got after registering on RTU software management platform, if there is no distribute ID. For more details, see as 2.2.4.
- Click "Apply" to finish, then power off RTU first and then reboot it again.


### 2.2.3. Login to RTU software management platform

Enter the RTU software management platform's IP address into the browser: <http://27.154.56.174:8091/LoginEnglish.aspx>, filled the user name and password that be distributed by Caimore to enter into the RTU software management platform.



1. Please push F5 or click "Home" or right click "home" to select "reload" to refresh continuously, till the icon of the relative RTU ID turn to green;
2. Select the relative RTU ID.

### 2.2.4. Register RTU ID




1. Click "Registration" on the top menu bar on the page.
2. You can manage the all the group by clicking "Add Group", "Modify Group", and "Delete Group".
3. All the details of current group can be displayed on the Group menu.
4. You will get a new RTU ID number when you click "Add device" and edit, also you can modify the device's parameters by clicking "Modify device".
5. You can find the details of RTU device if you click "details".
6. The RTU device will be deleted when you click "delete".

### 2.2.5. Setting connected interface

Each terminal device has multiple interface, which can be distinguished by name them. (for example: 1<sup>st</sup> relay):






1. Click "Resource Alias";
2. Click "+" on replay output row;
3. Name each reply output in the table.
4. Click "Save alias";
5. Click "Read alias" to confirm or enter into remote configure page to check.

Note: a. the ball window will close automatically during the configuration. We don't suggest you to confirm it by manual.

B. You can check if all the operation has been done by clicking "system management" on the right top of the menu bar, and then click "status record".

## 2.2.6. Digital input parameters configuration




| Home | 1 Digital input           | Resource_alias     | 8               | 7                  |               |               |                 |              |  |
|------|---------------------------|--------------------|-----------------|--------------------|---------------|---------------|-----------------|--------------|--|
|      | Synchronize configuration | Load configuration |                 | Save configuration |               |               |                 |              |  |
| NO.  | Alias                     | Enable or not      | Working mode    | Trigger Condition  | Alarm content | Alarm Phone   | Update Time(ms) | Level logic  |  |
| 1    | digital_1                 | Yes 2              | Query + alarm 3 | Low level 4        | 123 5         | 18205925040 6 | 0               | 0-Low 1-High |  |
| 2    |                           | No                 | Query           | Low level          |               |               | 0               | 0-Low 1-High |  |
| 3    |                           | No                 | Query           | Low level          |               |               | 0               | 0-Low 1-High |  |
| 4    |                           | No                 | Query           | Low level          |               |               | 0               | 0-Low 1-High |  |
| 5    |                           | No                 | Query           | Low level          |               |               | 0               | 0-Low 1-High |  |
| 6    |                           | No                 | Query           | Low level          |               |               | 0               | 0-Low 1-High |  |
| 7    |                           | No                 | Query           | Low level          |               |               | 0               | 0-Low 1-High |  |
| 8    |                           | No                 | Query           | Low level          |               |               | 0               | 0-Low 1-High |  |

1. Click "Synchronize configuration", which will at least to synchronize configuration once enter into this platform;
2. Select "YES" from drop-down box of "Enable" option;
3. Work type: To select the relative alarming mode, otherwise, no alarming. Alarming/active report's configure see as 2.2.7;
4. To set the alarm trigger conditions: Only valid for alarming. For active report, it will trigger an alarm when the time is up.
5. Enter the alarm contents.
6. The mobile phone number for alarming: up to 10 number, separated by ",".
7. Save the configuration parameters.
8. Click "Load configuration" to upload the configuration parameters or enter into RTU web-based management platform to ensure success.


**Note:** a. the ball window will close automatically during the configuration. We don't suggest you to confirm it by manual.

B. You can check if all the operation has been done by clicking "system management" on the right top of the menu bar, and then click "status record".

### 2.2.7. Alarming/Active reporting configuration



The screenshot shows a web interface with a dropdown menu titled "Remote\_configuration". The menu is open, displaying several options: "Common use", "Senior", "Router configuration", "DTU configuration", "Digital input", "Analog input", "PWM Output", "Counter", "Digital output", "Relay output", and "Active report". The "Active report" option is highlighted with a red box. The background shows a sidebar with "Home" and "Welcome to us" text, and a main area with "The following is the instructions how to use" and "Acquisition Control".




1. Click "Synchronize configuration", which will at least to synchronize configuration once enter into this platform.
2. Set "YES OR NO" from the drop-down box of "Active Report" option.
3. Alarm Report Mode: Network alarming and SMS alarming. (currently, the module of MC2716, mu609, M305 support SMS alarming; the others are only support network alarming, 2G communication module can not support SMS due to no SMS port);
4. To set active report interval time;
5. All receive numbers: All the serial data will be send for these mobile numbers.
6. Alarm Mode: Network alarming and SMS alarming. (currently, the module of MC2716, mu609, M305 support SMS alarming; the others are only support network alarming, 2G communication module can not support SMS due to no SMS port)。
7. To set alarm interval time;
8. Alarm times: if the value is 0, then RTU will send alarming info once time is up;
9. All alarm received numbers: All the serial alarm data will be send for these mobile numbers. By the way, each road count input has its own mobile NO. For alarming.

**Note:** a. the ball window will close automatically during the configuration. We don't suggest you to confirm it by manual.

B. You can check if all the operation has been done by clicking "system management" on the right top of the menu bar, and then click "status record".


### 2.2.8. Alarming query /Active reporting query configuration

### 2.2.8.1. Active Alarming query



1. All the alarm info of RTU will be displayed on this area.
2. To specific a certain time range that you query the alarm info of RTU ID device.

### 2.2.8.2. Active reporting query




1. All the active report info of RTU will be displayed on this area.
2. To specific a certain time range that you query the active report info of RTU ID device.

## 3. Remote control the digital input on RTU management platform

### 3.1. Enter into RTU management platform

Please refer to 2.2.3.

### 3.2. Configuration Digital input



1. Click "Acquisition" on the left top of the page;
2. Click "Synchronize configuration", which will at least to synchronize configuration once enter into this platform;
3. Click "Digital";
4. Click "Data Acquisition";
5. Click "Reading acquisition", all the selected data will be displayed on the page. And each current value will not changed unless RTU recollect the data again;
6. To display current digital input interface's value. This value will increase if you rising the relative rising edge plug.

Note: a. the ball window will close automatically during the configuration. We don't suggest you to confirm it by manual.

B. You can check if all the operation has been done by clicking "system management" on the right top of the menu bar, and then click "status record".

### Appendix 1: Indicator description

| Indicator | Status  | Description               |
|-----------|---|---------------------------|
| Power     | On  | Powered on                |
|           | Off   | Powered off               |
| ONLINE    | Off   | Have not adsl             |
|           | One Flash in a second and off in the next one   | Fail to find the SIM card |
|           | Twice Flash in a second and off in the next one | Fail to dial-up           |
|           | Trip Flash in a second and off in the next one  | Success to dial-up        |

|     |  |                                    |
|-----|--|------------------------------------|
|     | Light on in a second and off in the next one | Connecting to data center          |
|     | On   | Success to connect the data center |
| ACT | Flash  | Receive or send out data           |
|     | Off  | No data be receive or send out     |

## Appendix 2: Faulty analysis

### 4.1. Power indicator is off

Please ensure the cable be connected correctly, power supply meet the requirement and standards. Otherwise, it may will destroyed DTU.

### 4.2. Online indicator is off

Online indicator will not be on until RTU terminal access to network successfully. If it off, please ensure the network is normal, and check if SIM card be inserted correctly or data central server software can work normal, or the communication of TCP data is been intercepted by firewall.

### 4.3. ACT indicator is off


The ACT indicator of RTU with 3G network will never to flash. The others will turn on when there is some certain data be received or sent out.

### 4.4. All the indicators are normal, but it still can not to communicated.

Please check with local network operator that there is GPRS network in your area, also please ensure that the configuration of IP address and communication port is correct.

### 4.5. Too slowly to enter into RTU WEB page

If it is too slowly to refresh the RTU WEB page and frequently to drop RTU packet when you use PING IP command to testing, please to modify the RTU MAC address first. As it maybe caused by there is the same MAC address of RTU.



Basic

- WAN
- LAN 1**
- DDNS
- KeepAlive

Advance

**Lan Manage**

**Lan 1**

|   |                   |
|---|-------------------|
| IP  | 192.168.1.2       |
| Mask  | 255.255.255.0     |
| MAC   | 00:01:23:33:67:f0 |
| <input type="checkbox"/> DNS Servers (use the isp's dns as default) |                   |